

SSK1

Space Saver Plumbing Kit for Single Bowl Sinks.

Notes on installation.

Parts marked 'X' are connections for Dishwashers and Washing machines.

If none of these appliances are used, please ensure the blue blanking plug is in place at 'X' otherwise water will be spilled from these points..

It is also important to ensure that the blue plug is not in place when an appliance is fitted at 'X'.

If the plug is in this position, serious damage could result to the appliance.

It is important to ensure that the discharge hose is taken to the height stated by the appliance manufacturer, as illustrated below:-

