

HCUP50UK

Designed for use only with a syphonic urinal bowl having a horizontal spigot outlet. The seal depth is measured in combination with the urinal.

Fitting Instructions:

- 1) Solvent Weld the PVC 2" BS5255 x 50mm DIN adaptor to 2" waste pipe (2.2" OD).
- 2) Position the body and ensure the 50mm plain tail outlet passes through the bore of the adaptor without dislodging the 'O' ring. Ensure the 'O' ring is accessible should replacement be needed.
- 3) Secure the body to back panel prior to offering up the urinal.

Note: If connecting adaptor to ABS Pipe, ensure suitable PVC/ABS solvent is used.

