

Guidance Notes for Installation of CLAMP1GR & CLAMP1WH

- The Clamp is suitable for use with 1/4" & 1/2" plastic waste pipe to BSEN1451-1-2000 & BSEN1329-1-2000
- The Clamp should always be installed in a vertical position
- Establish the position where the Clamp is to be installed and drill a hole to a maximum diameter of 15mm. Ensure that the hole is clean and that the edge is smooth
- Select the appropriate 1/4" or 1/2" rubber seals and place over the locating spigots on A and B
- Place part A over the waste pipe making sure that the hole in the seal is directly over the hole in the pipe. Place part B on the underside and use the four screws provided to screw from the top through parts A and B to secure joint
- Universal outlet suitable for Ø19/23mm overflow pipe
- Black Seal to be used for Ø19/23mm rigid pipe and the White Seal for Ø25mm flexible pipe only
- Flexible connection is only possible on the bend as shown below and not on the Clamp Body.

